

Universalfuze

Kicker Key200.4 Processor Amplifier for VF Commodore Quick Installation Guide

Step 1

Remove the **Main Infotainment Module** behind the climate control dials and remove the top screen of your Mylink system.

Step 2

Unplug the main factory quadlock connector and plug in the **Universalfuze interceptor harness** supplied with your kit.

Step 3

Plug and Play the **Kicker Key200.4 Amplifier** to the interceptor harness then remount the **Main Infotainment Module**.

Step 4

Connect the **Kicker Key200.4 Amplifier's** (Black) Ground wire to the infotainment mounting bracket via the attached eyelet.

Step 5

Install the included 3.5" speaker to the top speaker mount on the dash and connect the two blue spade terminals to power it.

Step 6

Rest the **Kicker Key200.4 Amplifier** neatly on top of the **Main Infotainment Module** and reconnect all of the parts. Before reassembly, connect **Kicker Key200.4 Amplifier Microphone** and run the **Kicker Key200.4 Amplifier** tuning process (see below).

The FULL **Kicker Key200.4 Amplifier** tuning process and auto-setup walkthrough can be found in the product manual at the following URL:

<https://www.kicker.com/app/manuals/47KEY2004.pdf>

Step 7

Enjoy your new Kicker Processor Amplifier!